



1. DO NOT ATTACH DUCT TO TOP OF LOWER LOUVER BLADE AS TYPICAL. THIS CREATES SEALING PROBLEMS AT MULLIONS AND OTHER VERTICAL MEMBERS.
2. CONSTRUCT SLEEVE AND DUCTWORK TO SUPPORT WEIGHT OF SERVICE TECHNICIAN.
3. SEAL JOINT BETWEEN DUCT AND SLEEVE WATER TIGHT ALL AROUND.
4. INSULATE DUCT AND SLEEVE AS SPECIFIED.